

INSTRUCTIONS



***W*laneurop®**
RECIPROCATING COMPRESSORS

PTC CRANKCASE HEATER INSTALLATION

PTC CRANKCASE HEATER INSTALLATION

1- The kit contains :



2- Open the heat
conductive paste
tube



3- Put inside
the past inside
the heater well
(press on the
tube)



4- Insure a good
paste distribution



5- Insert the PTC



6- Insert the PTC
at the maximum



7- Insert the PTC
lock ring
(small diameter
of conical ring
ahead)



8- Push lock ring
in the PTC block
(until contact
with PTC)



9- Result



Danfoss

**Danfoss Commercial
Compressors**

BP 331 F-01603 Trévoux France
Tél. 04 74 00 28 29 - + 33 4 74 00 28 29
Fax 04 74 00 52 44 - + 33 4 74 00 52 44
<http://cc.danfoss.com>